# beyerdynamic

# USE CASES MAY 2019

# CONTENT

# See how Unite works in the following applications:

Guided tour Page 3: Guided tour with talkback Page 4: Guided tour with two guides Page 5: Guided tour with whispered interpretation (1) Page 6: Page 7: Guided tour with whispered interpretation (2) Page 8: Guided tour with two interpreters Page 9: External audio input Wireless microphone, PA, assistive Listening Page 10: Page 11:

Page 12: Multi room – wireless microphone, assistive listening
Page 12: Multi room – assistive listening with 3<sup>rd</sup> party mic

Page 13: Interpretation – multi language transmission Page 14: Interpretation – broadcast of 4 languages

Page 15 Assistive listening (without PA)

Page 16: Assistive listening

Page 17: Silent PA


Page 18: Silent PA with access point

Page 19: Wireless intercom Page 20: Blind coverage

Page 21: Legend


# **UNITE**GUIDED TOUR







# **UNITE**GUIDED TOUR WITH TALKBACK





### Talkback can be routed by the Master device to:


- 1. ALL = the whole group
- 2. Master device only
- 3. Master and all Sub-Master devices


# beyerdynamic





# **UNITE**GUIDED TOUR WITH TWO GUIDES







### Sub-Master signal can be routed by the Master device to:

- 1. ALL = the whole group
- 2. Master device only
- 3. Master and all Sub-Master devices






# GUIDED TOUR WITH WHISPERED INTERPRETATION (1)



# Interpreter

Receiver + Master 2








# GUIDED TOUR WITH WHISPERED INTERPRETATION (2)






### Setting on Master:


Menu: Talkback/Audio Routing/Sub-Masters/ shall be set to "Master" or "Master + Sub-Masters" This setting determines who can hear the submaster audio signals. beyerdynamic





## **GUIDED TOUR WITH TWO INTERPRETERS**





### Setting on Master:

Menu: Talkback/Audio Routing/RP Talkback/ shall be set to "Master + Sub-Masters" This setting determines who can hear the talkback audio signals from RP-T devices. beyerdynamic








# UNITE EXTERNAL AUDIO INPUT

# **Unite TP interfaces**





**Unite TP** 

### Use the Ducker!

Ducking is a common expression in sound engineering for giving specific automatic prominence to an audio signal. This is achieved by decreasing other signals rather than increasing the user signal to be given prominence. This effect can guarantee speech intelligibility. Depending on the setting, the USB, Bluetooth or analog AUX signal is lowered or suppressed as soon as the microphone source of the Unite TP is discussed.

### **Details on audio Sources:**

Regardless of whether your Unite TP is configured as master or sub-master, you have the option of importing external audio signals into the group via USB-C, Bluetooth or analog.

Please note the following special aspects:

### 1. USB-C

You can connect any computer to your Unite TP using a USB to USB C cable. Your computer will recognize the Unite TP as an audio interface for input and output. Not only can you play audio into the Unite TP, you can also output or record everything that has been routed to the TP in the group on a PC. By the way, ALL mobile Unite devices have this feature.

### 2. Bluetooth®

Bluetooth® can be used in two different configurations. Either as a headset (talk and listen) or as a PC/Phone for inputting and outputting audio signals. Please note that you can use either Bluetooth or USB. Both are unfortunately not possible at the same time. Bluetooth® is only available on the Unite TP.


### 3. Analog

The Unite TP has an analog AUX input via 3.5mm mini-jack. The recorded audio signal is summed to a mono signal.





MOBILE EVENT - WIRELESS MICROPHONE, PA, ASSISTIVE LISTENING




# beyerdynamic






# WIRELESS MICROPHONE, ASSISTIVE LISTENING - MULTI ROOM SOLUTION



Switch



Unite Manager

Monitoring
Configuration
Maintenance

Cat5e

beyerdynamic


digitalanalog






## ASSISTIVE LISTENING- MULTI ROOM SOLUTION 2

Cat5e



Switch



Unite Manager


Monitoring
Configuration
Maintenance

beyerdynamic

digitalanalog



# MULTI LANGUAGE TRANSMISSION (7+1 LANGUAGES)




beyerdynamic





# **BROADCAST OF 4 LANGUAGES**

# 3rd party audio source Dante or analog output











**Unite AP4** 

Master















# **Audience**

Receiver

























Option: IL200 for assistive listening

# Select individually:

Language 1 Language 2


Language 3

Language 4





**DECT Connections** 





# **UNITE**SMALL EVENT WITH ASSISTIVE LISTENING (WITHOUT PA)





# ASSISTIVE LISTENING – INCLUSION FOR THE HARD OF HEARING









or

3rd party

audio source












SILENT PA – SELECT YOUR ONE OF 32











beyerdynamic



### DIGITAL MULTICHANNEL TRANSMISSION - SILENT PA WITH ACCESS POINT



**Content 1** 

DECT 1

**Content 2** 

DECT 2



**Content 3** 

DECT 3



Content 4

DECT 4





beyerdynamic





## WIRELESS INTERCOM – COMMUNICATE OVER 300 METERS

300 m


# TRAINER/ COMMANDER Master





Unite TP + HSP321

# **TEAM**Receivers with Talkback



Unite RP-T + HSP321



- I. ALL = the whole group
- 2. Master device only
- 3. Master and all Sub-Master devices

# beyerdynamic

active talkback





# UNITE BLIND COVERAGE – WITH TWO REPORTER AND MONITORING

# Audience Receiver Waster Master Unite TP + DT 287 Unite Reporter 1 Master P+ DT 287 Unite Reporter 2 Sub-Master Unite TP + DT 287 Unite



### Sub-Master signal can be routed by the Master device to:

- 1. ALL = the whole group
- 2. Master device only
- 3. Master and all Sub-Master devices







# UNITE **LEGEND**




### **DECT Connection: Broadcast**

- Uni-directional (one way)
- One master device and unlimited receiver devices
- One speaker, many listener
- No backward channel













Master/ Sub-Master



DECT Connection: Full-Duplex

- Bi-directional
- Just two devices communicate (point-to-point)
- Two devices can speak and listen simultaneously
- Like a DECT phone: Base station and mobile device With Unite: Unite RP-T talkback and sub-master connections to master



Hint



Media rack






















**Assistive Listening** 



digital



analog

**Smart** device



Player

3rd party microphone

USB-C

Bluetooth®

Jack 3,5

# beyerdynamic

# THE PEOPLE

WWW.BEYERDYNAMIC.COM/UNITE